

# CONTROL ACCESSORIES

## RADIO TECHNOLOGY SOMFY® (RTS)

### TELIS COLLECTION



Telis 1 RTS Lounge  
Single Channel Remote  
1810650



Telis 4 RTS Lounge  
Five Channel Remote  
1810652



Telis 1 RTS Silver  
Single Channel Remote  
1810639



Telis 4 RTS Silver  
Five Channel Remote  
1810641



Telis 1 RTS Pure  
Single Channel Remote  
1810632



Telis 4 RTS Pure  
Five Channel Remote  
1810633



Telis 1 Soliris  
RTS Pure  
1810635



Telis 1 RTS Patio  
Single Channel Remote  
1810643



Telis 4 RTS Patio  
Five Channel Remote  
1810645



Telis 1 Soliris  
RTS Patio  
1810647



Telis 4 Soliris  
RTS Patio  
1811243



Telis 1 Modulis RTS  
Pure with  
Scroll Wheel  
1811234\*



Telis 4 Modulis RTS  
Pure with  
Scroll Wheel  
1811235\*



Telis 16 Channel RTS  
Pure Remote with  
On-screen display  
1811081



Telis 16 Channel RTS  
Silver Remote with  
On-screen display  
1811082

### DECOFLEX WIREFREE™ WALL SWITCHES & TABLE TOP ACCESSORIES



DecoFlex 1  
Channel RTS  
Wireless Wall Switch



DecoFlex 2  
Channel RTS  
Wireless Wall Switch



DecoFlex 3  
Channel RTS  
Wireless Wall Switch



DecoFlex 4  
Channel RTS  
Wireless Wall Switch



DecoFlex 5  
Channel RTS  
Wireless Wall Switch



DecoFlex Tabletop RTS  
Accessory Black  
1811051\*\*




DecoFlex Tabletop RTS  
Accessory Silver  
1810972\*\*



DecoFlex Tabletop RTS  
Accessory White  
1811185\*\*

Wall Switches shown in white. Also available in black, ivory, and almond finishes. Shown above assembled with printed channel buttons.



\*\*DecoFlex Switch sold separately from Table Top Accessory

\*Scroll wheel can only be used in conjunction with the Multi-link.